

# Quick Start Guide

Installation, Operation, Commissioning and Maintenance

356825.103

## Flatpack2 PS System, SP2

*Smartpack2*-based, DC Power Supply System  
Integrated 4U Distribution, Cabinetized and Outdoor Applications



Power Supply System ~ Telecom

### Introduction

- The *Smartpack2*-based Product Range (2)
- Brief Description, *Smartpack2*-based System (2)

### Installation

- Installing Rectifiers & Opening *Smartpack2 Master* (3)
- Installation steps; mechanical, electrical (4-5)
- Location of Components, GA Drawing (6)
- Connections, Factory Settings, etc. (7)

### Commissioning

- Pre-start check (8)
- Commissioning steps, Startup (8-9)

### Operation

- Front keys and display, Controller Access via PC (10)
- Software Menus – *Smartpack2 Master* Controller (11)

### Appendix

#### Communication

- CAN Bus Termination and Addressing (12)

#### AC Mains

- External AC Fuses, Recommended Rating (13)
- Identifying Power Shelves, 4AC, 2AC or 4AC-3kW (14)
- I. Individual AC Mains Terminals ~ NOT Reconfigurable (14)
- II. AC Mains Terminal Block ~ Reconfigurable (15)
- III. AC Terminal Block with SPDs ~ NOT Reconfigurable (16)
- About AC, DC Earthing Systems (17)
- Mains Phases vs. Rectifier ID – Phase Balancing & Monitoring (18-19)

#### Battery Monitoring

- Battery Monitor's 48V Symmetry Connections (20-21)

#### Internal Connections

- Standard Alarm Relays & Digital Inputs – Connections (22)
- LVD Latching Contactors – Connections (22)
- Replacing *Smartpack2 Basic* Controller, inside- or top cover-mounted...(23)

#### CAN Bus Nodes

- Battery Monitor CAN Node (24)
- Load Monitor CAN Node (25)
- I/O Monitor and I/O Monitor2 CAN Nodes (26)

### Check Lists

- Installation Check List
- Circuit Distribution List
- Commissioning Procedure
- Maintenance Procedure

pullout forms



ELTEK VALERE



# Introduction

## The Smartpack2-based Product Range

Eltek Valere's *Smartpack2*-based product range utilizes *Flatpack2* rectifiers and the *Smartpack2* distributed control system as building blocks for implementing effective DC power systems, suitable for a wide range of applications and power ratings.



*Flatpack2* Systems, SP2-based  
Indoor and Outdoor Cabinets




*Flatpack2* System, SP2-based  
Integrated 4U Distributions

Cabinetized systems are suitable for indoor or outdoor applications. In addition to the power system and the distribution unit, the cabinet may also contain battery banks, additional distribution and other dedicated equipment.

Integrated power systems consist of rectifiers, *Smartpack2 Master* and *Smartpack2 Basic* controllers, I/O Monitor2 nodes and the distribution unit (4U high). Integrated systems are sold primarily for mounting in existing cabinets.

## Brief Description — Smartpack2-based System

The *Smartpack2*-based *Flatpack2 PS* system is a compact, powerful and cost-effective DC power supply system, specifically developed for telecom and industrial applications.



Example of a typical *Smartpack2*-based *Flatpack2* system used for DC power supply of telecom and industrial equipment. The system is fed from an external AC mains supply, and consists of rectifiers in power shelves, master and basic controllers and DC distribution unit. Battery banks, LVD contactors, etc. are typically also a part of the system.



## Installing Rectifiers and Opening *Smartpack2 Master*




### CAUTION:

- The rectifiers may be warm, but **do not hand-carry** them by their handles
  - **Open the handles before inserting** them into the power shelves (hot-pluggable)
- The rectifier incorporates a Mains fuse in each line. Double Pole / Neutral Fusing



### Mounting or Removing *Flatpack2* Rectifiers

For an overview of available rectifiers, refer to “User Guide *Flatpack2* Rectifier Modules”, document 350002.013.




1. **Unlock the handles** by inserting a screwdriver into the holes to release the spring mechanism
2. **Insert or remove the rectifier** by sliding it fully into the power shelf, so that it makes proper contact or using both handles to pull the module loose. Support from underneath before the unit is completely free
3. **Lock the handles** by pushing the handles up into their housings (locked position). Then, the rectifier will be securely locked in the shelf, or ready for transport
4. **Mount blind panels** in unused rectifier locations



**CAUTION:** Do not relocate **already hot-plugged rectifiers** to other positions in the power shelf. **New rectifiers** must be hot-plugged in the power shelf, one at a time, starting from ID number 1, 2, 3 and so on; refer to page 19.

**WARNING:** To replace installed rectifiers with new ones, remove the installed rectifiers and wait for the controller to notify communication error with the extracted rectifiers. Push the new rectifiers fully into the power shelf — one module at a time, allowing a 2s delay. Start with the shelf position with lowest ID number. Lock their handles.




Blind panel's upper locking tabs

### Removing Blind Panels

1. **Release the panel's upper left and right corners** by inserting a small screwdriver into the panel's upper left gap and carefully press down and out to release the locking tabs. Repeat on the upper right gap.
2. **Remove the blind panel** by using your hand to pull the panel loose

### Mounting Blind Panels

1. **Insert the panel's upper edge** by pressing gently so that its upper locking tabs engage
2. **Lock the panel's lower edge** by pressing with your hand so that the blind panel's lower tabs lock into position.



### Opening and Closing *Smartpack2 Master* Controller


Opening the controller's right side enables inserting an SD card and temporarily connecting an Ethernet cable.

1. To open it, **pull the handle's knob slightly outwards** (use your fingers or a pen) and
2. then **slide the handle to the left** (the controller's right side opens)
3. To close it, **push the controller's front inwards**

Handle in locked position



Smartpack2 Master controller (locked)



SD card  
Handle in open position

Smartpack2 Master controller (open)



# Installation

## Installation Steps

Check off in the *Installation Check List*, that you find in the pullout section of this folder. Also, refer to the system's specific drawings.

### Preparing the Installation Site

Begin preparing the following:

- 1 Organize the installation site**
  - Min. clearances for cabinet access: 60 cm in front, 20 cm on top
  - Levelled surface able to support 600 kg (cabinetized systems)
  - Explosive atmospheres are to be avoided. Ensure suitable ventilation
  - 60V systems are only to be installed in Restricted Access Locations (RAL)
- 2 Prepare the installation tools**
  - Use insulated tools suitable for telecom installations
- 3 Prepare AC Supply: AC input cable(s) and fuses**
  - Correct type AC supply is available
  - External AC fuses have correct rating
  - AC input cable(s) are sized correctly





For external AC fuses and AC input cable ratings, refer to your site's AC supply specification. Read also our **external AC fuse recommendations** in section "*Appendix*". In general, a site with better AC supply quality (stable nominal voltage) may use smaller breakers.

### Mechanical Installation

Power is OFF!

Carry out the following:

- 4 Remove packaging and check equipment**
  - Check you have received all the parts, correct cabinet, documentation, batteries (if applicable), etc.
  - Inspect the equipment for physical damage (report any damages)
  - Leave rectifier modules in their packaging or in the selves, if factory installed. To be installed under commissioning
- 5 Remove top cover and dummy front panels**
  - Cable entry from the top. Connection terminals are located behind the upper dummy panels
  - Battery shelves (if any) are placed behind the lower panels
- 6 Position and fasten the cabinet or subassembly**
  - *Cabinets* are floor-mounted on levelled surface. Adjust the legs if necessary. If the cabinet must be fastened, unscrew the legs and use suitable bolts to fasten it to the floor
  - *Subassemblies* are fastened in existing 19" or in ETSI cabinets, using brackets. Mount the support & heat deflecting plate under the lower power shelf
- 7 Mount the batteries on the shelves**
  - Start (if applicable) placing the batteries on the lower shelf first, and continue upwards
  - *Do not terminate* the battery cables yet!







## Electrical Installation

Power is OFF!

Carry out the following: (Refer to the system's specific drawings)

General Torque Recommended Ratings, FP2 Systems	
Application, Type & Size	Torque (Nm)
<b>Circuit Breakers</b>	
SIEMENS 18 mm, 5SX2, 5SX5	3.5
SIEMENS 27 mm, 5SX6, 5SX7, 5SP4	5.0
MG, C60 ≤25A	3.5
MG, C60 >25A	3.5
CBI 13 mm, QY, QF, QA	3.0
<b>Hex Nuts &amp; Screws (Knife Fuses, general)</b>	
M8.0	10.0
M10.0	16.0
M12.0	25.0
<b>AC Terminal Blocks</b>	
1.5 mm <sup>2</sup>	0.5
2.5 mm <sup>2</sup>	0.5
4.0 mm <sup>2</sup>	0.6
10 mm <sup>2</sup>	2.0
16 mm <sup>2</sup>	3.0
35 mm <sup>2</sup>	4.0
70 mm <sup>2</sup>	10.0
<b>DC Rail Terminals</b>	
AKG 16	3.0
AKG 35	3.5

Note: General tolerance: ±10%.

NEC/CEC Requirements

### 8 Make the system completely voltage free

- Switch OFF or remove all load fuses (MCB1, MCBx), battery fuses (Fb1, Fbx) and the AC supply fuses, in external fuse boards

### 9 AC Connections

- *Check AC configuration:* the AC terminals are correct configured to the external AC supply, otherwise reconfigure the terminals
- *Connect the AC Earth wire (PE)* to the terminals AC Earth (PE)
- *Connect the AC input cable(s)* to the terminals. Cable and terminal block labeling are to correspond

### 10 DC Connections — Load Circuits

- *Terminate DC Earth (TE)*, and check that the common DC Output Rail is connected to “Telecom Earth” (TE) at only one place (at the cabinet or at a central distribution point). See chapter about AC, DC earthing systems
- *For each DC load*, connect one of the cables to the common DC output rail, and the other directly to the MCB or load fuse

### 11 DC Connections — Alarm & Signal Circuits

- Refer to your system's connection drawings and configuration, or to the “Appendix, CAN Bus Nodes” section (Factory Settings)
- *Terminate Alarm Circuit cables* to the relay output terminals
- *Terminate Signal Circuit cables* to the digital input/output terminals

### 12 DC Connections — Battery Cables

**CAREFUL!** Use correct polarity.


For 48V systems using the battery symmetry mid-point measurement, refer to the figure in this page.

For other measurement methods and for 24V systems, refer to the Battery Monitor's user guide.

For each battery shelf:

(In cabinetized systems, steps b, d and f are usually performed in factory)

- Mount 3 intercell links* to connect in series 4 battery blocks
- Connect battery cables* to fuses and common DC rail, and to the shelf's outer terminals; (+) and (-)
- Connect battery symmetry cable*, if applicable, to the input terminal, and to the center terminal of the battery string (+). Deviation from factory settings requires Symmetry reconfiguration via *PowerSuite*
- Connect the temperature sensor cable*, if applicable, to the input terminals, and fix the temperature sensor (at the end of the cable) to a suitable place in the middle of the installed battery bank






# Installation

## Location of Components, GA drawing

The pictures show an example of the location of components in *Smartpack2*-based *Flatpack2* PS Systems with 4U DC Distribution. Or refer to **specific drawings** included with your system.


The *Smartpack2 Basic* controller is located either inside the subassembly (picture below) or under the top cover (see chapter on page 23).





## Connections, Factory Settings, etc

The schematic shows the connection terminals in *Smartpack2*-based *Flatpack2* PS Systems with 4U DC Distribution. Or refer to **specific drawings** included with your system.





# Commissioning

The commissioning of *Flatpack2 PS System* consists of following stages:

- I. Perform a pre-start check before the PS system is switched ON
- II. Switch ON the system with disconnected load; adjust output voltage
- III. Adjust the nominal output voltage with connected batteries and load

## I

### Pre-Start Check

Power is OFF!

Check off in the *Commissioning Procedure*, that you find in the pullout section of this folder.

If you have just finished the system installation successfully and filled in the *Installation Check List*, jump over the Pre-Start Check and continue with stage II.

Before you switch ON the *Flatpack2 PS* system, verify the following:

#### 1. System installation is completed

- Ensure a correctly performed system installation, with correct polarity on all connections, has been carried out (*Installation Check List* filled in)
- All cabling and copper bars are securely terminated and supported
- All components, terminal blocks, MCBs/ fuses, etc. are clearly labeled

#### 2. Battery and load fuses are disconnected

- Verify that all battery and load MCBs/ fuses are switched OFF or removed

#### 3. AC input cable(s) and AC Earth wire (PE) are terminated

- Make sure that the AC input cable(s) are connected to correctly configured AC terminals
- Verify that the AC input cable(s) and external AC fuses are sized and rated as specified
- Check that AC Earth (PE) is terminated, and electrically connected to chassis

#### 4. Site specific parameters and settings are known

- Read the system specific drawings and documentation

#### 5. AC supply and all MCBs, fuses are switched OFF

- Make sure that all external AC fuses and internal MCBs/ fuses are switched OFF



Device Hazard

## Commissioning Steps, Startup

Check off in the *Commissioning Procedure*, that you find in the pullout section of this folder.

After the "Pre-start Check" is performed, you can begin with stage II. During the stage, you will switch ON the *Flatpack2 PSS* — while the batteries and load are disconnected — then measure the output voltage, and adjust it if required. Carry out the following:

## II

### Startup and No-Load Adjustments

Power is ON!

#### 1. Disconnect all rectifier modules, without removing them (keep original location)

- Read how to install modules, on page 3 in this guide. Also, read about the correct rectifier position on page 19, and then,
- If *Flatpack2* rectifier modules are installed, unlock the handles and pull the modules partially out (fan housing visible), but do NOT physically remove them from the power shelves
- If *Flatpack2* rectifier modules are not yet mounted, release their handles and insert them partially into the correct position in the shelves

#### 2. Switch ON the system

- Switch ON the AC input supply (external AC fuses) to the PS cabinet

#### 3. Measure and verify that the AC input voltage is correct

- Measure the AC input voltage at the cabinet's mains connection box
- Verify the AC voltage is within range



Device Hazard





4. **Mount all *Flatpack2* rectifier modules in the power shelves (keep original location)**
  - Push all rectifiers firmly inwards — one module at a time, allowing a 2s delay — to plug them in the same shelf location. Lock their handles. Refer also to page 19
  - Mount blanking panels over unused positions
5. **Ensure that the *Smartpack2 Master* controller and all rectifiers are working: LEDs are ON**
  - Verify correct operation, by monitoring the modules' LED lamps and display:  
No alarms are present on rectifiers; The controller displays fuse alarms
6. **Connect a PC to the PS system (to facilitate operation)**
  - Plug a standard Ethernet cable between the PC and the *Smartpack2 Master* controller
  - Start the “*Eltek Valere Network Utility*” program and establish access to the controller. Refer to chapter “Controller Access”, page 10, if required
  - Log in and access the controller's configuration pages in your Web browser
7. **Measure and adjust DC output voltage**
  - Read the DC output voltage on the controller's display
  - With a multi-meter, measure the DC output voltage at the most accessible point, e.g. between the common DC rail and the lower connection of one of the priority load MCBs
  - If required, adjust the voltage using the controller's front keys or via the PC's browser
8. **Verify the alarm relays are working correctly (alarm relay test)**
  - Run the alarm relay test using the controller's front keys (refer to page 10) or via the PC's browser
9. **Make sure the *System Setup* is in accordance with configuration**
  - Verify system settings using the controller's front keys or via the PC's browser
  - Use the opportunity to enter site related information, number of used AC phases, type of batteries, etc.

## Load Adjustments

Power is ON!

III

Now, you can begin with stage III, where you will adjust again the output voltage to the battery voltage, and connect the batteries and the load. Carry out the following:

10. **Adjust DC output voltage to equal measured battery voltage**
  - Measure the battery voltage is within range (*check connections have correct polarity*)
  - Adjust DC output voltage — using the controller's front keys (refer to page 10) or via the PC's browser — to equal the measured battery voltage.  
(Important adjustment to avoid arcing when connecting the batteries)
11. **Unplug all rectifiers but one, and connect the battery fuses /MCBs**

**CAUTION:** Have *only one* rectifier connected when switching ON the battery fuses, thus avoiding damaging all rectifiers, due to possible incorrect polarity connections, etc.

  - Disconnect all rectifiers but one, by unlocking the handles and pulling them partially out (fan housing visible). Do NOT physically remove them from the power shelves
  - Switch ON all battery fuses or MCBs
12. **Adjust DC output voltage again to equal the nominal battery voltage**
  - Adjust DC output voltage — using the controller's front keys or the PC's browser — to equal the nominal battery voltage (or the nominal load voltage, when not using batteries)
13. **Plug in again all rectifiers, and verify the rectifiers' current sharing**
  - Connect all rectifiers again by pushing them firmly inwards — Repeat step 4, in stage II
  - Wait for about 2 min., and check — using the PC's browser — that each of the rectifiers delivers the same output current. A deviation of 1A is acceptable.
14. **Connect the load breakers and verify that no alarms are displayed**
  - Switch ON all load MCBs/ fuses
  - Verify correct operation: rectifiers and controller display no alarms






## Operation






### Front Keys and display, Controller Access via PC



#### Smartpack2 Master Controller — front panel

**Display:** is in *Status Mode* (displays the system's status) or in *Menu Mode* (displays the menu structure).

**Operation:** Press on the  key to change from *Status Mode* to *Menu Mode* and to select options, enter values.

Press the  key to navigate to previous level and cancel options and values. Press the  or  keys to navigate up- or downwards, point at options and increase and decrease values. Press the  or  keys to navigate one page up- or downwards and point at options.

**Menus:** When you "enter" *Menu Mode*, you access the *Main Menu* (Level 1). Default pin code <0003> (should be changed) is used to change parameters.



#### Flatpack2 Rectifier Module — front panel

**Power LED** is **OFF** (mains unavailable), **Flashing** (controller accessing information) or **ON** (powered). **Warning LED** is **ON** (derating or similar minor warning), **Flashing** (over-voltage mode) or **OFF** (OK)

**Alarm LED** is **ON** (shutdown or similar major alarm) or **OFF** (OK, no alarm)

### Controller Access — Via Stand-alone PC

You can access the *Smartpack2 Master* controller directly from a stand-alone computer, or via a Local Area Network (LAN) if available. Each controller is shipped with a unique *Eltek Valere* MAC address stored inside the controller and marked on the controller's label, and with the fixed IP address <192.168.10.20>. Do the following to access the controller:




1. **Start the "Eltek Valere Network Utility" (EVNU) program (EVIPSetup.exe)**
2. **Connect the computer to the controller;** check its MAC address is displayed
3. **Find the computer NIC's IP address and subnet mask (network card)**  
Tip: e.g. using DOS command IPCONFIG in a Command Prompt window  
e.g. computer's IP address <169.254.52.132> Subnet mask <255.255.0.0>
4. **Change the controller's IP address and Network Mask to the same range as the computer's (using the EVNU program)**  
Tip: 1. Select the controller, 2. Click in the "Configuration" button 3. Change from e.g. default <192.168.10.20> <0.0.0.0> to IP address <169.254.52.133> <255.255.0.0>, 4. Click on the "Enable Static IP" button
5. **Access the controller's configuration pages in your web browser (from EVNU)**
6. **Log in** with the <admin> account,
7. Change the controller's Device Name

After accessing the controller, you can configure and monitor the power system with a standard web browser (via *WebPower*) or via the *PowerSuite* program. *PowerSuite*'s newest version is always available on our FTP server. Contact your closest *Eltek Valere* representative.



## Software Menus — Smartpack2 Master Controller


The *Smartpack2*-based DC power system's functionality is accessed via a network of software menus and submenus, enabling you to configure and control the whole power system from the controller's front panel. When browsing the menus, the Menu Level Indicator shows where you are, the menu level you are in. Editing parameters is password protected, (default pin code <0003> should be changed). The display can be in *Status Mode* or in *Menu Mode*.



From a PC's web browser, via *WebPower*, or running the *PowerSuite* program, you can also access the complete system functionality, described in the programs' Online Help.



## CAN Bus Termination



*Flatpack2* systems are shipped from factory with the CAN bus already terminated with 120Ω resistors.

To ensure a correct bus communication and avoid data reflection, you must *always* terminate the CAN bus with two 120Ω resistors, one at each end of the line (60Ω bus impedance). The figure shows a *Flatpack2* system communicating via the CAN bus.

## CAN Bus Addressing

All rectifiers and control units (controllers and CAN nodes) connected to the *Eltek Valere's* CAN bus must have a unique address or ID number. The power system's master controller assigns automatically the rectifiers' addresses (**software assignment**). The master controller registers the rectifiers' ID numbers – or CAN bus address (01, 02 ...) – together with their Serial Numbers.

The power system's control units make use of DIP switches for configuring their unique CAN bus ID number (**hardware assignment**). The only exception is the *Compack* and *Smartpack2 Master* controllers, which have factory assigned specific ID numbers <1> and <11> (not changeable).

In the control system's CAN bus, you can address a maximum of 14 CAN nodes of each type, 8 *Smartpack* and *Smartpack2 Basic* controllers and 8 *Smartnode* units. See table below:


Number of nodes >> Control Units' Name	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	
Smartpack & Smartpack2 Basic Controllers	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	<< ID #
Smartnode Control Units	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	<< ID #
Battery Monitor CAN nodes	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	<< ID #
Load Monitor CAN nodes	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	<< ID #
**	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	<< ID #
I/O Monitor & I/O Monitor2 CAN nodes	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	<< ID #
Mains Monitor CAN nodes	97	98	99	100	101	102	103	104	105	106	107	108	109	110	111	112	<< ID #

*ID numbers formatted in grey italics are not available due to software constraints.*

\*\* Only 4 of the 8 mounted DIP switches may be used (max. 14 Load Monitors may be connected).

For DIP switch configuration, refer to actual control unit's guide or to *WebPower* Help.

The figure shows a *Flatpack2* DC power system with *Smartpack2*-based control system and 4 CAN nodes to implement additional digital inputs, relay outputs or similar functionality.










### Identifying Power Shelves: 4AC, 2AC or 4AC-3kW



Flatpack2 rectifiers are accommodated in one or several power shelves. Following types of power shelves are available:


- **4AC Power Shelves**, or single AC feed, 1 TB (4 AC inputs per shelf, each feeding 1 rectifier)
- **4AC-3kW Power Shelves**, or single AC feed, 2 TB (4 AC inputs per shelf, each feeding 1 rectifier)
- **2AC Power Shelves**, or dual AC feed, 1 TB (2 AC inputs per shelf, each feeding 2 rectifiers)

You can identify the type of power shelves used by your system by reading the shelf's label, or by looking at the shape of the shelf's AC mains terminals, at its rear; (viewable by removing the rectifier in the shelf's 1<sup>st</sup> and or 4<sup>th</sup> position). Also, 4AC-3kW power shelves are longer in depth, and have 2 terminal blocks (TB).

### I Individual AC Mains Terminals ~ NOT Reconfigurable

Mains reconfiguration is NOT possible when the system is shipped with *fixed* individual Mains input terminal blocks.

Such systems have to be configured at the factory prior to delivery.






## II AC Mains Terminal Block ~ Reconfigurable

To reconfigure the AC mains feed of *Flatpack2* DC power systems that use the AC Mains terminal block, you have to reconnect the AC mains wires and fishplates on the terminal block.

1. **Switch OFF** the AC supply fuses in external fuse boards
2. **Check that** your system is implemented with **4AC-3kW or 4AC powers shelves** (read the Identifying Power Shelves section, page 14). If your system utilizes 2AC power shelves, you can NOT reconfigure it as described in this section
3. **Connect** the AC Mains wires to the AC terminal block, **and mount** the fishplates, **according to the type of AC mains to be used**, as shown in the actual example in this section



Cable section for all AC Mains wires: 10mm<sup>2</sup> max.

**Warning:**



Ensure that no excess material sticks out from the fish plates' sides after cutting, thus avoiding damaging short-circuits between them



### III AC Terminal Block with SPDs ~ NOT Reconfigurable

Mains reconfiguration is **NOT possible** when *Flatpack2* DC power systems are shipped with **AC terminal blocks with SPDs**<sup>2</sup>. Such systems have to be configured at the factory prior to delivery.

Refer also to page 7 for more information about connection to Digital Input 1 on *I/O Monitor2* CAN node.



<sup>2</sup> Surge Protective Device (SPD), also called overvoltage protectors or surge arresters






## About AC, DC Earthing Systems

To prevent the risk of electric shock, all cabinet's chassis are to be electrically connected to AC Earth (PE). Also, it is a common practice for telecom equipment to have its common DC output rail (+ or -) connected to a separate "Telecom Earth" (TE) or DC Earth.

PE (Protective Earth)  
TE (Telecom Earth)  
EG (Exchange Ground)



Earth connections are in particular important where frequent lightning might induce high voltage levels in AC supply and in battery and load cables.



At factory, AC Earth (PE) and DC Earth (TE) are connected to chassis. Remove "Link EG" ("floating earth") for compliance with other local earthing systems.

Refer to your system's **specific drawings** to identify how earth connections are implemented in your DC power system.

"Common Positive DC Output Rail" is usual in 48 and 60V DC supply systems: *Negative DC Distribution*. "Common Negative DC Output Rail" is usual in 24V systems: *Positive DC Distribution*.






## Mains Phases versus Rectifier ID

## Phase Balancing &amp; Monitoring

When *Flatpack2* systems are fed with a 3-phase AC Mains input circuit, each rectifier is internally connected to the 230VAC phases, in such a pattern that loads the 3 phases evenly.

The distribution of rectifiers among the phases is implemented both via internal wiring to the power shelves, and how the shelf's back-wiring card routes the phases to each rectifier position. There are 3 types of shelves: 4AC, 4AC-3kW and 2AC power shelves. Read also the *Identifying Power Shelves* section, page14.



## Plug-and-Play Rectifiers versus Phase Monitoring

When a rectifier is **hot plugged in a power shelf for the first time**, the system's master controller assigns the next available ID number to the rectifier, starting with "01". The controller registers the rectifier's Serial Number and ID number.

When a **previously installed (hot plugged) Flatpack2** rectifier is inserted in a power shelf, the master controller "recognizes" the module, and assigns the same ID to the rectifier. In other words, the controller and the rectifier "remember" the assigned ID number, even after removing and reinserting the rectifier in the shelf.

To achieve a more controlled ID assignment, you should always insert & hot-plug new *Flatpack2* rectifiers **in the indicated power shelf position, one module at a time, starting with ID number 1, 2, 3**, and so on. The sequence is indifferent after ID number 6. You find more information on page 19.

This position-versus-ID number relationship is very important, as the controller always uses rectifier IDs 01 and 04 to monitor mains phase L1, rectifier IDs 02 and 05 to monitor mains phase L2 and rectifier IDs 03 and 06 to monitor mains phase L3. When both rectifiers, monitoring the same phase, report that the **mains phase voltage is lower than the configured limit**, then the controller broadcasts a "Mains Phase Lx" warning (one phase has failed).

For example: accidentally inserting a rectifier with ID02 in a power shelf position internally connected to mains phase 1, will cause the controller to monitor phase 1 "thinking" it monitors phase 2. Then a phase 1 fault will be alarmed as a phase 2 fault.



### Correct Rectifier Positions in Power Shelves

*Flatpack2* DC power systems are normally shipped from factory with empty power shelves. The rectifier modules are shipped in separate packaging, and you have to install the modules in the correct position in the power shelves, with respect to their ID number (or CAN bus address). Do not relocate already pre-installed rectifiers.


For first time installations of rectifiers in *Flatpack2* systems, follow the scheme below:

1. Find out your system's power shelf type, by reading the *Identifying Power Shelves* section, page 14
  2. Find out if your system's AC mains feed is <230VAC, 3 phase> or <400VAC, 3 phase and N>
  3. Insert & hot-plug the rectifiers in the indicated power shelf positions, one module at a time, allowing a 2s delay between them and starting with ID number 1, 2, 3, and so on. (indifferent after ID# 6)
- Follow one of the four figures (I, II, III or IV) below:

#### Smartpack2 Master and Smartpack Located in Distribution Shelf


##### Correct Rectifier Position in 4AC Power Shelves (I)

Single AC feed: 4 AC inputs per shelf, each feeding 1 rectifier




##### Correct Rectifier Position in 2AC Power Shelves (II)

Dual AC feed: 2 AC inputs per shelf, each feeding 2 rectifiers




**Notice:**  
For *Smartpack2*-based systems follow figure I or II, as the *Smartpack2* Master controller is always mounted in the distribution shelf. The examples in the figures show *Smartpack*-based systems.



#### Smartpack Located in Power Shelf


##### Correct Rectifier Position in 4AC Power Shelves (III)

Single AC feed: 4 AC inputs per shelf, each feeding 1 rectifier



##### Correct Rectifier Position in 2AC Power Shelves (IV)

Dual AC feed: 2 AC inputs per shelf, each feeding 2 rectifiers





## Battery Symmetry Connections


Smartpack2-based systems use *Battery Monitor* CAN nodes for battery symmetry measurements.

### Battery Monitor's Symmetry Connections — 48V (Block Measurement)

Each *Battery Monitor* is equipped with 4 battery symmetry inputs, enabling symmetry measurement of 1 battery string using the *Block Measurement Method*.

Read the installation guides for *Battery Monitor CAN Node* (351507.033) and for *Battery Monitor – Symmetry Kit* (351497.033), which is included with the kit.

Example of Battery Symmetry Connections on the *Battery Monitor*, 48V Systems



**Notice:**  
Always connect *Battery Monitor* with ID#<33> to battery string 1 (lowest), with ID#<34> to string 2, and so on. The controller will then refer to the correct battery string.






### Battery Monitor's Symmetry Connections — 48V (Mid-Point Measurement)

Each *Battery Monitor* is equipped with 4 battery symmetry inputs, enabling symmetry measurement of 4 battery strings using the *Mid-Point Measurement Method*.


Read the “*Installation Guide Battery Monitor CAN Node*”, document number 351507.033. Refer also to “*Installation Guide Battery Monitor – Symmetry Kit*”, document number 351497.033, which is included with the kit. The Battery Fuse and Battery Current cables are not shipped with the *Battery Monitor ~ Symmetry Kit*.





## Standard Alarm Relays &amp; Digital Inputs

## Connections



The alarm outputs in *Flatpack2* systems use the *Fail-Safe Operation Mode* (relay coils energized in the system's normal operation mode). When the system is in alarm mode, the alarm relay coils are de-energized.

The figure shows the position of the relay contacts when the relay coils are de-energized (PS system in alarm mode)


In order to implement monitored fail-safe digital inputs circuits, the external relay coil must be energized and the contacts closed in the system's normal mode of operation.

## LVD Latching Contactors

## Connections

*Flatpack2* systems' LVBD and LVLD<sup>[3]</sup> functionality is implemented with magnetically latching contactors<sup>[4]</sup>.

The coil of latching contactors is not energized in any state. They change state from open to close, or vice versa, when a reversed pulse is applied to the coil.



<sup>[3]</sup> LVBD, Low Voltage Battery Disconnect; LVLD, Low Voltage Load Disconnect

<sup>[4]</sup> *Smartpack2*-based *Flatpack2* systems may be implemented with latching and with non-latching contactors



## Replacing the *Smartpack2 Basic* Controller

The *Smartpack2 Basic* controller is always factory installed either under the subassembly's top cover or inside the subassembly. The length of the controller's connection cables is suitable for mounting in both locations.



**CAUTION:**  
When the *Smartpack2 Basic* controller is mounted under the top cover, you must unfasten the controller (steps 1-3) before you can remove the top cover (step 4)


### Fastening/Unfastening Inside-Mounted Controllers

To **unfasten** the *Smartpack2 Basic* controller from the power system, switch OFF the power system, and

**Power is OFF!**

1. Loosen the top fixing tab screw from the screw hole (D)
2. Lift the controller carefully upwards, (the slot (C) disengage from the lower fixing tab (B))
3. Unplug the cables from the CAN bus sockets
4. Disconnect the pluggable I/O terminals by pulling them out

To **fasten** a new *Smartpack2 Basic* controller to the power system, first configure its CAN ID address and then, in the inverse order, carry out the opposite as described above (4, 3, 2, 1).




### Fastening/Unfastening Top Cover-Mounted Controllers

To **unfasten** the *Smartpack2 Basic* controller from the top cover, switch OFF the power system, and

**Power is OFF!**

1. Open the power system's front panel
2. Loosen the fixing tab screw (A)
3. Slide the controller to the left — so that its tab disengage from the top cover's fixing tab (B) — and let the controller rest on the breakers
4. Slide the top cover towards the front and remove it (the CAN bus and I/O cables can now be disconnected)






## CAN Bus Nodes

The CAN Bus Nodes are control units connected to the power system's CAN bus. They have a rugged sealed-plastic design, with DIN-rail or Velcro tabs as standard mounting options.

When the CAN bus address is configured and the unit connected to the bus, it will automatically communicate with the power system's controller ("plug and play"). Configure then the CAN node functionality using *WebPower* or *PowerSuite*.

### Battery Monitor CAN Node

The *Battery Monitor CAN Bus Node* enables you to decentralize or increase the number of battery symmetry measurements in your *Compact*-, *Smartpack*- or *Smartpack2*-based DC power supply system. Also, it monitors the battery compartment temperature – using the built-in sensor – the battery fuse – with a fuse monitoring input – and the battery current – via a current sense input.




Battery Monitor  
DIP switch configuration



ID <33>  
(All switches OFF)

Battery Monitor	ID #	DIP Switch Position 1 — 2 — 3 — 4
1 <sup>st</sup> Monitor	33	OFF—OFF—OFF—OFF
2 <sup>nd</sup> Monitor	34	ON—OFF—OFF—OFF
3 <sup>rd</sup> Monitor	35	OFF—ON—OFF—OFF
4 <sup>th</sup> Monitor	36	ON—ON—OFF—OFF
5 <sup>th</sup> Monitor	37	OFF—OFF—ON—OFF
6 <sup>th</sup> Monitor	38	ON—OFF—ON—OFF
7 <sup>th</sup> Monitor	39	OFF—ON—ON—OFF
8 <sup>th</sup> Monitor	40	ON—ON—ON—OFF
9 <sup>th</sup> Monitor	41	OFF—OFF—OFF—ON
10 <sup>th</sup> Monitor	42	ON—OFF—OFF—ON
11 <sup>th</sup> Monitor	43	OFF—ON—OFF—ON
12 <sup>th</sup> Monitor	44	ON—ON—OFF—ON
13 <sup>th</sup> Monitor	45	OFF—OFF—ON—ON
14 <sup>th</sup> Monitor	46	ON—OFF—ON—ON

**Note:**  
• The monitor's ID # corresponds to the DIP switch's binary value plus 33




Read also the "Installation Guide Battery Monitor CAN Node", document 351507.033.





### Load Monitor CAN Node

The *Load Monitor CAN Bus Node* enables you to decentralize and increase the number of input fuse monitoring and current sense signals in your *Compact*-, *Smartpack*- or *Smartpack2*-based DC power supply system. The fuse monitoring inputs are suitable for monitoring a wide range of breakers in both positive and negative DC distributions.




Read also the “Installation Guide Load Monitor CAN Node”, document 351506.033.

Load Monitor	ID #	DIP Switch Position 1 — 2 — 3 — 4			
1 <sup>st</sup> Monitor	49	OFF	OFF	OFF	OFF
2 <sup>nd</sup> Monitor	50	ON	OFF	OFF	OFF
3 <sup>rd</sup> Monitor	51	OFF	ON	OFF	OFF
4 <sup>th</sup> Monitor	52	ON	ON	OFF	OFF
5 <sup>th</sup> Monitor	53	OFF	OFF	ON	OFF
6 <sup>th</sup> Monitor	54	ON	OFF	ON	OFF
7 <sup>th</sup> Monitor	55	OFF	ON	ON	OFF
8 <sup>th</sup> Monitor	56	ON	ON	ON	OFF
9 <sup>th</sup> Monitor	57	OFF	OFF	OFF	ON
10 <sup>th</sup> Monitor	58	ON	OFF	OFF	ON
11 <sup>th</sup> Monitor	59	OFF	ON	OFF	ON
12 <sup>th</sup> Monitor	60	ON	ON	OFF	ON
13 <sup>th</sup> Monitor	61	OFF	OFF	ON	ON
14 <sup>th</sup> Monitor	62	ON	OFF	ON	ON

Load Monitor  
DIP switch configuration


ID <49>  
(All switches OFF)

- Note:**
- DIP switch positions 5 through 8 are always to be OFF
  - The monitor's ID # corresponds to the DIP switch's binary value plus 49





## I/O Monitor and I/O Monitor2 CAN Nodes


**Notice:**

The figure shows the location of terminals and LEDs in the *I/O Monitor* node.  
The *I/O Monitor2* node implements the same input and outputs as the *I/O Monitor* node (X:\*, X:\*\*), except for the Fan Control signals (X:\*\*\*).

The *I/O Monitor* and the *I/O Monitor2* CAN Bus Nodes enable you to decentralize and increase the number of input monitoring and output controlling signals in your *Compact*-, *Smartpack*- or *Smartpack2*-based DC power supply system.

Also, the *I/O Monitor* node monitors and controls the compartment temperature inside fan-cooled outdoor cabinets.

Read also the installation guides for *I/O Monitor CAN Node* (document 351503.033) and for *I/O Monitor2 CAN Node* (document 351509.033).



I/O Monitor	ID #	DIP Switch Position
		1 — 2 — 3 — 4
1 <sup>st</sup> Monitor	81	OFF—OFF—OFF—OFF
2 <sup>nd</sup> Monitor	82	ON—OFF—OFF—OFF
3 <sup>rd</sup> Monitor	83	OFF—ON—OFF—OFF
4 <sup>th</sup> Monitor	84	ON—ON—OFF—OFF
5 <sup>th</sup> Monitor	85	OFF—OFF—ON—OFF
6 <sup>th</sup> Monitor	86	ON—OFF—ON—OFF
7 <sup>th</sup> Monitor	87	OFF—ON—ON—OFF
8 <sup>th</sup> Monitor	88	ON—ON—ON—OFF
9 <sup>th</sup> Monitor	89	OFF—OFF—OFF—ON
10 <sup>th</sup> Monitor	90	ON—OFF—OFF—ON
11 <sup>th</sup> Monitor	91	OFF—ON—OFF—ON
12 <sup>th</sup> Monitor	92	ON—ON—OFF—ON
13 <sup>th</sup> Monitor	93	OFF—OFF—ON—ON
14 <sup>th</sup> Monitor	94	ON—OFF—ON—ON





This product is CE marked and complies with all current requirements for relevant standards and directives.

[www.eltekvalere.com](http://www.eltekvalere.com)

Copyright © *Eltek Valere*, 2011  
This document may be changed without notice

Art. No. 356825.103, Issue 2.0, 2011 Sep  
Published 2011-10-07

Headquarters:

**Eltek Valere**

Gråterudv. 8, Pb 2340 Strømsø, 3003 Drammen, Norway  
Phone: +47 32 20 32 00 Fax: +47 32 20 32 10



## Check Lists Pullout

Pull out the pages with the gray outer band,  
and use them as check lists

# INSTALLATION CHECK LIST

## System Data

Flatpack2 PS System

Flatpack2 Power Supply System, type:		Article No.:	
Site, name:			
Serial No.:	Software, version No.:	Rectifiers, type & number of:	
AC Input Voltage, measured:	Battery Type:	Battery Capacity:	Installation carried out by, name:

## Site Preparations



CARRY OUT FOLLOWING:	OK
<b>1. Organize the installation site</b> <ul style="list-style-type: none"> <li>Check min. clearances for cabinet access: front access, 60cm, top access, 20cm</li> <li>Check that the levelled surface is able to support 600 kg (cabinetized systems)</li> <li>Ensure the installation site is suitably ventilated and in a non-explosive atmosphere. 60V systems in RAL areas</li> </ul>	<input type="checkbox"/>
<b>2. Prepare the installation tools</b> <ul style="list-style-type: none"> <li>Check that insulated tools suitable for telecom installations are used</li> </ul>	<input type="checkbox"/>
<b>3. Prepare AC Supply: AC input cable(s) and fuses</b> <ul style="list-style-type: none"> <li>Check the AC supply is the correct type, and that the external AC fuses and AC input cable(s) are suitably rated</li> </ul>	<input type="checkbox"/>

## Mechanical Installation

Power is OFF!



CARRY OUT FOLLOWING:	OK
<b>4. Remove packaging and check equipment</b> <ul style="list-style-type: none"> <li>Check you have received all the parts, correct cabinet, documentation, batteries (if applicable), etc</li> <li>Inspect the equipment for physical damage (report any damages)</li> <li>Leave rectifier modules in their packaging or in the selves, if factory installed. (commissioning task)</li> </ul>	<input type="checkbox"/>
<b>5. Remove top cover and dummy front panels</b> <ul style="list-style-type: none"> <li>Check that cable entry from the top is possible</li> </ul>	<input type="checkbox"/>
<b>6. Position and fasten the cabinet or subassembly</b> <ul style="list-style-type: none"> <li>Cabinets on levelled surface, adjust the legs. If necessary, unscrew the legs and fasten the cabinet to floor</li> <li>Subassemblies in existing 19" or in ETSI cabinets, using brackets. Mount the support &amp; heat deflecting plate</li> </ul>	<input type="checkbox"/>
<b>7. Mount the batteries on the shelves</b> <ul style="list-style-type: none"> <li>Start (if applicable) on the lower shelf first, and continue upwards</li> <li>Do not terminate the battery cables yet!</li> </ul>	<input type="checkbox"/>

## Electrical Installation

Power is OFF!



CARRY OUT FOLLOWING:	OK
<b>8. Make the system completely voltage free</b> <ul style="list-style-type: none"> <li>Switch OFF or remove all load fuses (MCB1, MCBx), battery fuses (Fb1, Fbx) and external AC supply fuses</li> </ul>	<input type="checkbox"/>
<b>9. AC Connections</b> <ul style="list-style-type: none"> <li>Check AC configuration: The AC terminals are correct configured to the external AC supply</li> <li>Connect the AC Earth wire (PE) to the terminals AC Earth (PE)</li> <li>Connect the AC input cable(s) to the terminals. Cable and terminal block labeling are to correspond</li> </ul>	<input type="checkbox"/>
<b>10. DC Connections — Load Circuits</b> <ul style="list-style-type: none"> <li>Terminate DC Earth (TE): Common DC Output Rail is connected to TE at only one place</li> <li>For each DC load, connect one of the cables to the common DC output rail, and the other directly to the MCB</li> </ul>	<input type="checkbox"/>
<b>11. DC Connections — Alarm &amp; Signal Circuits</b> <ul style="list-style-type: none"> <li>Refer to your system's connection drawings and configuration, or to the Factory Settings in the Quick Start Guide</li> <li>Terminate Alarm Circuit cables to the relay output terminals</li> <li>Terminate Signal Circuit cables to the digital input/output terminals</li> </ul>	<input type="checkbox"/>
<b>12. DC Connections — Battery Cables</b> <p>Careful! Use correct polarity.</p> <p>For each battery shelf,</p> <ul style="list-style-type: none"> <li>Mount 3 intercell links to connect in series 4 battery blocks, (In 24V systems: 1 link and 2 blocks)</li> <li>Connect battery cables to fuses and common DC rail, and to the shelf's outer terminals; (+) and (-)</li> <li>Connect battery symmetry cables, if applicable, to the input terminals</li> <li>Connect the temperature sensor cable, if applicable, to the input terminals, and fix the sensor (at the end of the cable) to a suitable place in the middle of the installed battery bank</li> </ul>	<input type="checkbox"/>

## Approval

Responsible of installation, sign.:	Date:	Approved by customer, sign.:
-------------------------------------	-------	------------------------------

# CIRCUIT DISTRIBUTION LIST

## System Data

Flatpack2 PSS, type:	Article No.:
Site, name:	

CIRC.	NO.	FUSE KNIFE	TYPE MCB	LVD CONTROLLED	DESCRIPTION	FUSE AMPERE	CABLE mm <sup>2</sup>
BATT.	Fb1						
	Fb2						
	Fb3						
	Fb4						
	Fb5						
	Fb6						
LOAD	F1						
	F2						
	F3						
	F4						
	F5						
	F6						
	F7						
	F8						
	F9						
	F10						
	F11						
	F12						
	F13						
	F14						
	F15						
	F16						
	F17						
	F18						
	F19						
	F20						
	F21						
	F22						
	F23						
	F24						
	F25						
	F26						
	F27						
	F28						
	F29						
	F30						
	F31						
	F32						
	F33						
	F34						
	F35						

Continue

## CIRCUIT DISTRIBUTION LIST

# LOAD



# MAINTENANCE PROCEDURE

## System Data

Flatpack2 PS System

Flatpack2 Power Supply System, type:			Article No.:
Site, name:			
Serial No.:	Software, version No.:		Rectifiers, type & number of:
AC Input Voltage, measured:	Battery Type:	Battery Capacity:	Maintenance carried out by, name:



**WARNING: Maintenance work on live equipment is only to be performed by authorized and qualified persons using calibrated instruments of measurement and insulated tools. Hazardous voltages inside may cause terminal injury.**

## System Inspection

Power is ON!

CARRY OUT FOLLOWING:	OK
1. Site specific parameters and settings are known. User manuals and site specific connection & arrangement drawings are available.	<input type="checkbox"/>
2. The battery bank has been fully charged in advance. At least for 12 hours since start-up or mains failure. Enables correct measurements & calibration	<input type="checkbox"/>
3. The equipment is free from damage, dust or dirt; verify. Carefully vacuum clean or remove any accumulation of dust, corrosion or dirt.	<input type="checkbox"/>
4. All cabling and copper bars are securely terminated and supported. Correct any loose connections, excessive cable temperature, defective insulation, etc.	<input type="checkbox"/>
5. The system controllers & all rectifier modules are ON, no alarm present; verify. Otherwise, correct and put the PS system in normal mode of operation.	<input type="checkbox"/>
6. All rectifier's functionality & controller's keys and display work OK; verify Correct possible abnormalities before continuing.	<input type="checkbox"/>
7. Connect the system's controller to a PC (Ethernet connection) Access the controller from the PC's web browser, thus enabling system configuration	<input type="checkbox"/>
8. Rectifiers' load current sharing; verify. (Using the keypad on the controller or from the PC) Check all rectifiers output the same amount of current ( $\pm 1A$ )	<input type="checkbox"/>
9. Display the stored log of Alarm Messages. Using the keypad on the controller or from the PC.	<input type="checkbox"/>

## System Adjustment

Power is ON!

CARRY OUT FOLLOWING:	OK
1. DC Output Voltage Calibration; ensure correct display readings. If measured DC output voltage at the load terminals deviates more than $\pm 1\%$ from the display reading, calibrate the output voltage from the controller's keypad or the PC.	<input type="checkbox"/>
2. Load & Battery Current Calibration; verify correct display readings. Measure with a clip-on ammeter the battery current & every load circuit current. Calculate the total load & battery current. If the calculated total values deviate more than $\pm 2\%$ from the display readings, calibrate the current from the PC (calibration value > 50% of system's max. capacity)	<input type="checkbox"/>
3. DC Output Voltage Adjustment; measure and adjust. Measure and, if required, adjust the output voltage to the nominal voltage recommended by the battery manufacturer. (Voltage measurements to be done at the DC rail, with little load current)	<input type="checkbox"/>
4. Alarm Relay Test; verify all alarm relays are working correctly. From the controller's keypad or PC use the Relay Test function; verify activation of external equipment	<input type="checkbox"/>
5. Battery bank control; measure and verify battery specifications. Follow the recommendations of the actual battery manufacturer.	<input type="checkbox"/>

## Approval

Responsible of maintenance control, sign.:	Date:	Approved by customer, sign.:
--	-------	------------------------------

Form 171-gb-v5-C01\_356825-103\_qstart\_flatpack2-4u-dist-sp2-syst\_2v0.docx\_mafe\_2010-05-25

[www.eltektvalere.com](http://www.eltektvalere.com)

Headquarters:  
Eltek Valere  
Gråterudv. 8, PB 2340 Strømsø, 3003 Drammen, Nor  
Phone: +47 32 20 32 00 Fax: +47 32 20 32 10





# COMMISSIONING PROCEDURE

## System Data

*Flatpack2 PS System*

Supplier's Order No.:	Flatpack2 Power Supply System, type:		Article No.:
Site, name:			
Serial No.:	Software, version No.:		Rectifiers, type & number of:
AC Input Voltage, measured:	Battery Type:	Battery Capacity:	Commissioning carried out by, name:

## I

### Pre-Start Check

Power is OFF!



#### CHECK FOLLOWING:

	OK
1. Flatpack2 system installation is completed; <small>The Flatpack2 Installation Check List is filled in.   All cabling is securely terminated with correct polarity</small>	<input type="checkbox"/>
2. All battery and load MCBs/ fuses are disconnected	<input type="checkbox"/>
3. AC input cable(s) and AC earth wire (PE) are terminated	<input type="checkbox"/>
4. Site specific parameters and settings are known	<input type="checkbox"/>
5. AC supply and all MCBs/ fuses are switched OFF	<input type="checkbox"/>

## II

### Start-up, No-Load & Load Adjustments

Power is ON!



#### CARRY OUT FOLLOWING:

	OK
1. Disconnect all rectifier modules, without removing them (keep original location)	<input type="checkbox"/>
2. Switch ON the system (external AC fuses ON)	<input type="checkbox"/>
3. AC input voltage is correct; <small>Measure and verify</small>	<input type="checkbox"/>
4. Insert all Flatpack2 rectifiers in their original locations in the power shelves	<input type="checkbox"/>
5. The Smartpack2 Master and all rectifier modules are working, LEDs are ON; <small>Verify</small>	<input type="checkbox"/>
6. Connect a PC to the PS system <small>Use a standard Ethernet cable and access the controller</small>	<input type="checkbox"/>
7. DC output voltage; <small>Measure and adjust</small>	<input type="checkbox"/>
8. Alarm relay test; <small>Verify all alarm relays are working correctly</small>	<input type="checkbox"/>
9. System Setup is in accordance with configuration <small>Enter site spec. info via front keys or PC</small>	<input type="checkbox"/>
10. Adjust DC output voltage to equal measured battery voltage <small>Check correct polarity!</small>	<input type="checkbox"/>
11. Unplug all rectifiers but one, and connect all battery fuses/ MCBs	<input type="checkbox"/>
12. Adjust DC output voltage to equal nominal battery or load voltage	<input type="checkbox"/>
13. Plug in again all rectifiers, and verify the rectifiers' current sharing	<input type="checkbox"/>
14. Connect all load MCBs/ fuses, and verify no alarms are displayed	<input type="checkbox"/>



### Approval

Responsible of commissioning, sign.:	Date:	Approved by customer, sign.:
--------------------------------------	-------	------------------------------

# Check Lists Pullout

Pull out the pages with the gray outer band,  
and use them as check lists