



Control Module (SC0500-40S) Front Interface




POWERCUBE H1

NEBO

FORCE H2




RJ45	-	RS232
pin 3	->	02 TX
pin 6	->	03 RX
pin 7+8	->	05 GND



RS232 Pin Out
Connector:
D-Sub Female 9 pins

**REDUKCE
RJ45-RS232**



**PŘEVODNÍK
RS232-USB**

